


RACE AMERICA

INNOVATION. TECHNOLOGY. RELIABILITY.



2700 Series XL Wireless Drag Race Timing System Owner's Manual

Rev N

RaceAmerica Corporation
105 Bonaventura Drive
San Jose, CA 95134
(408) 988-6188
www.raceamerica.com
info@raceamerica.com

Copyright 2020 RaceAmerica Corporation

Table of Contents

PRODUCT INFORMATION LINKS	3
HIGH PERFORMANCE BATTERIES - LiFePO4	4
THEORY OF OPERATION	5
QUICK START GUIDE	6
PACKAGE COMPONENTS	7
AVAILABLE OPTIONS	7
LOCAL REQUIREMENTS	8
PRODUCT SPECIFICATIONS	8
BEAM EMITTER AND TRACK SENSOR OPTIONS	9
TRACK SENSOR and BEAM EMITTER OPERATION	10
WIRELESS OPERATION	12
SET-UP STEPS - 2700 SERIES	12
DTSS TREE ASSEMBLY	15
T-LINK WIRELESS UNIT	16
TRACK LAYOUT - SENSORS/CABLING DIAGRAM	17
KEYPAD FUNCTION	18
NAVIGATING TIMER MENUS	18
DEFINITIONS of the TREE LIGHTS	19
POWER ON/SELF TEST	19
BACKGROUND MONITORING	20
SINGLE or DUAL LANE OPERATION	21
DIAGNOSTICS MENU	21
SYSTEM MENU	22
CONFIGURE MENU	24
RUNNING A RACE	26
TIME of DAY& COUNTDOWN FUNCTIONS	26
KEYPAD FUNCTIONS	28
STATUS DISPLAY MESSAGES	29
TROUBLE SHOOTING	30
CONNECTING PERIPHERAL DEVICES	31
RACE MANAGEMENT SOFTWARE	32
WIRELESS FIRMWARE UPDATE	32
MAINTENANCE	32
SPARE PARTS	33
SUPPORT AGREEMENTS	33
TIMESLIP HEADER WORKSHEET	34
FOAM STAND ASSEMBLY	36

RACE AMERICA

INNOVATION. TECHNOLOGY. RELIABILITY.

PRODUCT INFORMATION LINKS

RaceAmerica Website	www.raceamerica.com
RaceAmerica Online Store	store.raceamerica.com
Raceamerica Online Forum	www.raceamerica.com/forum
Product Warranty	www.raceamerica.com/legal.html
Service & Repairs	www.raceamerica.com/service.html
Technical Assistance	www.raceamerica.com/techcall.html
Owner's Manuals	www.raceamerica.com/prodpdf.html
Mounting Diagrams	www.raceamerica.com/mountpdf.html
Product Catalog	www.raceamerica.com/catalog.html

High Performance Batteries Lithium Iron Phosphate (LiFePO₄)

Congratulations on your recent purchase of race timing equipment from RaceAmerica. This equipment contains high performance lithium ion batteries. This document provide guidance to optimize Lithium based batteries for years of use.

BACKGROUND

High performance Lithium battery technology is quite different from other battery technologies. Lithium batteries can retain higher charge capacity in a smaller and lighter package. There is no memory to the Lithium battery to contend with but Lithium does have one drawback, they are more sensitive to misuse. Care must be taken to avoid overcharging and draining the batteries to avoid permanent damage. The equipment using Lithium batteries contains protection circuitry to reduce the chance of misuse. In conjunction with preventative care, the chance of permanent damage to the batteries is eliminated.

CHARGING

Use only battery chargers designed for Lithium batteries. This type of charger is designed to match the charging characteristics of the Lithium battery. Lithium battery chargers are available in several voltages and must match the voltage of the battery pack. Using a non Lithium battery charger will damage the Lithium batteries reducing their ability to charge to full capacity. Using a charger rated at a voltage different than the battery pack, both lower and higher voltage rating, will cause permanent damage to Lithium batteries.

Charge the batteries after each use. Lithium batteries will bleed off the charge slowly over time. This is not a 'charge memory' issue like other rechargeable batteries, it is the nature of Lithium batteries to bleed off some level of charge. The longer the batteries remain unused, the more the charge is reduced. Prior to next use, connect the charger to top off the charge.

Lithium batteries are unlike Sealed Lead Acid (SLA) batteries when trickle charging over periods of time. Lithium batteries can be overcharged if left on the charger for an extended period of time causing permanent damage to the battery cells. Discontinue charging when the charge LED indicator turns green indicating the Lithium batteries are at their recommended charge capacity.

STORAGE

Store your timing equipment containing Lithium batteries in a cool, dry place. Elevated temperatures increase the slow loss of charge and low temperatures decrease the charge capacity of the batteries. Extreme temperatures, high or low, can cause permanent damage to the Lithium chemistry of the battery.

If batteries are to be stored for an extended period of time, top off the battery charge every 30 days as described under charging above. This insures the charge does not drop below minimum levels and will require a short period of charge compared to charging after use.

THEORY OF OPERATION

The 2700 Series Drag Timers are dual microprocessor controlled completely self-contained race timing systems utilizing the latest CMOS technology circuit components to provide a highly accurate wireless drag timing solution. The system contains internal quartz crystal clocks to maintain time accuracy and display of race results to one thousandth of a second (0.001 sec) and multiple microprocessors to manage the data collected on the track.

The wireless data management of the system represents a true break through in race timing methodology. RaceAmerica uses proprietary technology blended with industrial grade wireless technology to give ease of use and accuracy. Each sensor trip (beam break) is retained locally and transmitted (usually within 0.5 sec) to the main control at the Console. This is the key to maintaining accuracy in increasingly cluttered radio frequency air space.

The Beam Emitters and Track Sensors operate on invisible (to the unaided human eye) Infra-red light. The coded light frequencies are constantly received by the Track Sensors until a car interrupts reception ('breaks' the beam). Sensor trips are monitored by T-Link wireless modules and transmitted back to the main timer control at the console. Time accuracy is maintained at 0.001 seconds.

The IR Beam Emitter to Track Sensor transmission operates on Line-of-Sight principles. This makes alignment of the units critical but simple. These units will operate over a wide range of conditions (full sun to total darkness) but should not be operated beyond the specification parameters (4 ft to 50 ft).

Once the system is properly set up and aligned on the racing surface, the timer console will 'monitor' the track sensors each time a run is made.

In racing mode, the system microprocessors take control of checking for a valid set of start conditions (expected blocked and unblocked sensors), then starts the lights (with adjustment for Full and Pro formats as well as any bracket or index adjustments) while watching for a start in either lane (a foul start will freeze the tree at the point of foul), records Reaction Time for each lane as the racers start. The system then watches for subsequent beam interruptions at the 60ft, 330ft (101M), 660ft (201M) Speed and ET, 1000ft (305M) Speed and ET and lastly Q-mile 1320ft (402M) Speed and Finish. After all data is collected, NHRA rules are applied to determine the winner and display this on the tree and console plus output to PCs, printers and Scoreboards connected to the system. Data includes RT, Redlights, ET, winner indication, Dial-in times, breakouts and total time.

The 2700 is intended for use with XLscore Pro PC software or operated independantly.

2700 XL Wireless Quick Start Guide

This Quick Start guide can be helpful to use as a set of steps to follow for relatively experienced operators of the XL Wireless system.

- 1 Set up timing system hardware and cabling on race surface
- 2 Power on all T-Links and Infra-red Beam Emitter units
- 3 Connect all peripheral devices such as printers and scoreboards
- 4 Power on all printers and scoreboards; observe scoreboards for proper power up sequence.
- 5 Power on timing system at the Tree; observe light sequences for proper power up sequence.
- 6 Power on Console and any connected Wireless Link units
- 7 Go into Alignment Mode [*5#] and check alignment at all sensor locations. No counting digits means everything is aligned. Exit Alignment Mode [#] when done.
- 8 Go into System Config [*4] and the Configuration menu [*8] to set desired operating parameters
- 9 Select PRO or FULL starting lights [3]
- 10 If running brackets, enter Dial-in times [6]
- 11 If printing results, enter Car # [9]
- 12 Stage racers
- 13 Start race [0] or use the optional Starter's Button
- 14 Press [#] to return to main menu and clear last race
- 15 Next Race? Go to [9] or [12]

PACKAGE COMPONENTS**The standard configuration for Model 2700 XL Wireless dual lane drag package includes*:**

1 - 2700 Series Console Unit factory configured with the following features:

- Selectable Speed Trap 10', 66', 3M or 20M
- Selectable Speed in MPH or KPH (Euro)
- Standard or Custom Timeslip Header
- Selectable Full/Pro Tree starting formats

- 1 - 02-2712 - Professional 110VAC LED Tree
- 1 - 05-3251 Tree to Start Cable (35 ft)
- 2 - 5063 Dual Emitters (Pre-Stage/Stage)
- 2 - 5163 Dual Sensors (Pre-Stage/Stage)
- 1 - 6017B - Speed/Finish Option
- 2 - 5843 T-Link3 modules ('C'/'D' IDs)
- 2 - 5042 IR Beam Emitters
- 4 - 5140 IR Track Sensors
- 2 - Cable Speed/Finish (06-5830)
- 1 - Owner's Manual

With these parts, the system will provide Pre-Stage, Stage, Reaction Time (RT), Elapsed Time (ET), Speed and winner indication for two lanes.

Model 2700 Available Options

Tree Options:

02-2512 - SST 110/230 VAC LED Tree with driver facing lights only.

Stage/Start Options:

- 6022A Single Beam Stage/Start
 - 2 - 5058 IR Beam Emitter
 - 2 - 5158 IR Track Sensor
- 6026A Dual Beam Staging - add Guard
 - 2-Dual IR Beam Emitters
 - 2-Dual IR Track Sensors
- 6023A Pre-Stage Electronics - add Pre-Stage and Guard beams
 - 2-Tri-Beam Emitters
 - 2-Tri-Beam Sensors

ET/Speed Options:

- 6017A 60 Ft ET
 - 2 - 5040 Beam Emitters
 - 2 - 5140 Sensors
 - 1 - 05-3251 Tree to 60 Ft cable
- 6017D3 Add 330ft/101M ET

- 2 - 5843 T-Link3 modules (G/H IDs)
- 2 - 5140 Sensors
- 1 - 5042 Beam Emitter
- 2 - Cable 05-5825

6017BM Add Mid-track ET/Speed

- 2 - 5843 T-Link3 modules (E/F IDs)
- 4 - 5140 Sensors
- 2 - 5042 Beam Emitter
- 2 - Cable Speed/Finish (06-5830)

6017D1 Add 1000ft/305M Speed/ET

- 2 - 5843 T-Link3 modules ('J'/'L' Units)
- 2 - 5140 Sensors
- 1 - 5042 Beam Emitter
- 2 - Cable Speed/Finish (06-5830)

6512 AC Adapter for wireless (9VDC, 12V OK)

6502 AC Adapter for console (12VDC/3A)

T-Link3 reconfigure kit

High Gain Yagi Antenna

Antenna Extension Kit

7540 Foam Stands

06-27SB Starter's Button - 100 foot cable

6045Dot-Matrix Timeslip Printer Package

3128B XLscore PRO-W Race Management

Software for PCs

3128A XLscore II Race Software for PCs

6828/6628/6428 Single Line Dual

Lane Digital Scoreboard

(8/15/24" digits respectively)

6810/6610/6410 Dual Line Dual Lane

Digital Scoreboard

(8/15/24" digits respectively)

4528D Dial-in boards (5in Digits)

4520 Wireless RF Data Link

6070 Storage/Carry Cases

* Part numbers are for domestic operation

(900 mhz Wireless); a 'X' suffix part number designates international (2.4Ghz)

** Pre-stage operates via a console program button unless a Pre-Stage start option is available.

LOCAL REQUIREMENTS

Additional items required to operate the 2700 Series timing system package and options:

Batteries for Beam Emitters (see table pg 8)
LED AC TREE - 120VAC 5A circuit

AC TREE
1 -110VAC 5Amp circuit/230VAC 5Amp
1 - Surge Suppression Power Strip (10A)

NOTE:

Most RaceAmerica cables are custom made using some of the components of Ethernet cables. Purchased ethernet cables are different than the RaceAmerica cables and should never be used as damage may result.

PRODUCT SPECIFICATIONS

The following listing provides the designed performance specifications for the 2700 Series timing systems:

2700 XL Wireless

Start Lane Width	4 to 40 feet
Finish Lane Width	4 to 50 feet
ET Timer Capacity	up to 90.000 sec
RT Timer Capacity	up to 9.999 sec
Time Accuracy	0.001 seconds
Minimum Speed 10ft Trap	1.70 MPH
	66ft Trap 11.25 MPH
AC TREE Dimensions	82" X 20" X 20"
DTSS TREE Weight	88 pounds
Power Requirements:	
DTSS TREE	110/230 60W
SST TREE	110/230 35W
Emitters	AA/C batteries

5843 T-Link3

Frequency (domestic USA)	900MHz
	(International) 2.4 GHz
Internal Battery (Li-Ion)	9.6VDC 3.3AH
T-Port Connections (relative to 1320ft/403M track)	
ID 'C'	Lt Full-track Speed/Finish
ID 'D'	Rt Full-track Speed/Finish
ID 'E'	Lt Mid/660ft Speed/ET
ID 'F'	Rt Mid/660ft Speed/ET
ID 'G'	Lt 330ft/101M ET
ID 'H'	Rt 330ft/402M ET
ID 'J'	Lt 1000ft/305M Speed/ET
ID 'L'	Rt 1000ft/305M Speed/ET
ID 'Z'	2700 Console
Connection Type	RJ-45 Modular
Max Operating Range	-20°F to 120°F
Battery Life	24 hours

Beam Emitter and Track Sensor Options

Standard



5140E Sensor



5040C/5042C Emitter

Used for 60Ft, Speed and Finish track locations. Emitters utilize USB rechargeable battery pack.

6022 Option



5158E Sensor



5058C Emitter

Start Line Sensors and Emitters are used for single beam Stage/Start. Emitters use USB rechargeable battery pack.

Standard




5163 Dual Beam Sensor



5063 Dual Beam Emitter

Pre-Stage and Stage Use USB rechargeable battery pack.

6026 Option



5156 Dual Beam Sensor



5054 Beam Emitter

Professional Dual Beam Sensors and Emitters add Guard upgrade for ATV and Snowmobile applications. Use 4 'C' batteries for each emitter.

6023 Option




Model 5167 - Tri-Beam Sensor



Model 5067 - Tri-Beam Emitter


Professional Triple Beam Sensors and Emitters are an upgrade option used to add Pre-Staging and a Guard beam for all applications. Use USB rechargeable battery pack.

Sensor and Emitter operation



The Emitter throws a spot light like beam of infra-red light; the Sensor should be aligned near the center of the beam for optimal reception and alignment.

Dual-Beam Sensor (5163)



Tri-Beam Sensor (5167)




Fig 1 Sensor/Emitter Alignment

OPERATION

Track Sensors & Beam Emitter Operation


RaceAmerica utilizes a variety of Track Sensors and Beam Emitters in its timing systems. All operate on line-of-sight infra-red beam principles. The beam is created by the Beam Emitter and received by the Track Sensor. The operating specification is for a gap of between four and fifty feet between the Emitter and Sensor. These will operate in conditions ranging from full sun to total darkness without adjustment when properly aligned. The Beam Emitters require a power source (batteries or AC adapters) while the Track Sensors are powered from the cable to the T-Link or Tree. The infra-red beam is a coded frequency which is detected by the sensor. Different frequencies are used for different locations in different systems. Beam Emitter voltage should not fall below 4.5 Volts DC while operating.

The beam operates on a generally established condition (ie, the sensor senses the presence of the beam), and is interrupted (broken) by the racer (beam blocked). The beam will automatically re-establish after being blocked. The detection of vehicles passing through the beam rapidly highlights the sophistication of this technology. In fact, many small items such as leaves, water, snow can interrupt the beam. RaceAmerica minimizes the impact of these occurrences by requiring multiple short interruptions of the beam to indicate an interruption as well as verification of beam conditions before a race is allowed to start.

RaceAmerica Professional Dual-beam and Tri-beam Sensors utilize multiple infra-red frequencies due to the close proximity of each sensor to positively insure the correct signal is broken or blocked. This is why track position and orientation is critical.

RaceAmerica Single Beam Staging/Start Emitters/Sensors (5058/5158) operate in both


Fig 2 - Beams, Wheels and the Starting Line



NOTE: Check your local practice for placement and alignment of beams on the track. Most tracks place the Stage beam on the physical starting line while others place the Guard beam on the physical starting line. The difference between the two is 16 inches

blocked and unblocked modes depending on system conditions. The unblocked mode allows for alignment check. The mode is reversed once a car has staged (blocked the beam) and the system is about to start a race. The ET timer for a lane will start when the beam changes phase as the vehicle pulls away.

RaceAmerica offers several different sensor and emitter models (see Beam Emitter and Sensor models); depending on a variety of requirements. See the table of Sensor/Emitter combinations which operate with the Model 2700 XL Wireless system. In general, non-similar sensor/emitter pairs will not function correctly. All start line sensor options connect to the same Start cable connections; make sure left and right lane positions are correct.



Wireless Operation

The wireless features of this system have greatly simplified set-up and tear down but must be followed carefully. Sensor alignment can be checked locally at each T-Link module as well as on the Console and mirrored to the Tree. The wireless T-Link transceivers operate best on line-of-sight principals; the Console unit is the main event coordinator. Keeping antennas up and off the ground as high as possible will optimize performance. The console can show the Radio Frequency (RF) Integrity on a relative basis between the various units. The system will operate correctly with low RF Integrity values however the system may have obvious delays while retries are accomplished during RF interference. Due to the nature of the technology, no timing accuracy is lost. Antenna extension kits

are available if necessary. All system components for racing (T-Link IDs 'A' thru 'L' plus 'Z') must be on the same Optimizer Code; peripheral devices such as scoreboards and printers may be on different codes. If other systems are operating in the vicinity (within several miles), they must be on different Optimizer Codes (see RaceAmerica for unique codes). **Do not operate any wireless device without the antenna on and do not operate wireless units within six feet of each other.**

The console keypad utilizes dual function keys. All functions shown in white function when pressed; functions shown in yellow require the * [SHIFT] key to be pressed two seconds before the desired function key is pressed.

The console also can display the battery charge level in each T-Link unit; charge batteries below 50% charge and before each event; charging may take 2 hours for each battery. The charger LED light will turn green when charging is complete and the units are 'topped-off'. A charged T-Link will operate for 14 hours between charges. T-Links should be 'topped-off' every thirty days when not being used.

The 2700 XL Wireless system has numerous configurable options such as type of Tree and Speed Trap which are saved after configuration in the console and tree. Operation of this wireless system is tolerant of many seemingly problematic situations. The technical design permits T-Link track units to be powered OFF/ON without missing more than one set of data; likewise with the Tree and Console and any peripheral devices. Generally, if a problem has occurred, end race **ENTER [#]** or the system reset **RESET [*0]** will automatically sync up all modules for operation and time accuracy to begin the next race.

SET-UP STEPS - 2700 SERIES

The content of this manual is designed to assist the new system owner with the RaceAmerica system, however, it is strongly suggested that the system be set up in a race simulation area to gain familiarity with basic operation of the components prior to race day. This can be done in a driveway or garage. Walking through beams can simulate

vehicles for purposes of familiarizing oneself with basic operation.

STEP 1 - Familiarize yourself with the components pictured in this manual and how they interconnect. See the track layout diagrams for proper placement of each component. The T-Link units are location specific (see label on the bottom of each T-Link). Spare ID 'C' T-Links can be reconfigured for another position on the track (with the T-Link reconfigure kit). Ensure the correct sensor is connected at each position (with the matching emitter opposing it)

The Speed sensors/emitters are placed immediately before the measured ET time and spaced at the configured trap length (10ft, 66ft or 20M).

STEP 2 - Identify the emitter/sensor

placement at the start line and finish line. The lane width should be set between four (4) and fifty (50) feet (optional 5050 Emitters have 75 ft range). Refer to the Track Sensors/Cabling Diagram page. Avoid running any of the system cables in conduit with 110/230VAC power lines as intermittent failures may occur. Speed Trap sensor spacing must match the system configuration to record accurate speeds. To help in determining initial beam emitter to track sensor alignment in wide track widths, eyeball a straight line between units. The system Alignment Mode will be utilized to verify alignment after power-up as well as using the T-Link units to view alignment locally.

STEP 3 - Assemble the Tree to the base as

XL Wireless Console Connectors




Fig 4 - Cable connectors on the underside of the XL Wireless console.

These are NOT Ethernet cables!!!

shown in the setup photos. Multiple base plates may be required for windy racing conditions. Install flood lamps on the AC Tree models.

STEP 4 - Place the electronic equipment in position as shown in diagram on page 14; connect the various cables. The tree should be about 30 feet out from the starting line.

STEP 5 - Connect cables for optional Starter's Button, Printer(s), PC(s), PODs, Wireless Links and Scoreboards to the appropriate connectors. The system will operate without these options connected. See Connecting Peripheral Devices for details about these options. Install antennas on all wireless link units including the back of the tree and console.

Minimize the number of any other devices (such as PA systems) on the same electrical circuit as the timing system. When running power and data cables, do not run them in the same conduit.

STEP 6 - Prepare to connect the system to the power source.

For the AC Tree option, connect the Tree to the AC power source. With AC power, a surge suppression power strip may be required at the Tree to compensate for line voltage fluctuations.


Operating the system from a battery connected to a charger or running car engine will result in an over voltage condition and damage the timer.

Go to Power-on/Self-test section to actually apply power to the various system components.

Fig 5 - DTSS TREE ASSEMBLY

The DTSS Tree as seen from the back bottom with post stand stored and clamped inside. The removable Tree Electronics module is shown on the right (actually left side of Tree from the front).

Fig 5 shows the post partially extended. There is an internal stop so the post will not come out too far. Loosen/tighten the clamp nuts on the U-bolt (9/16 in deep socket) at the desired position. Four 1/4-20 wing nuts secure the post to the base.



DTSS Tree bottom

Post extension



The DTSS Tree Electronics module can be removed for service.

Unplug the Tree before proceeding.

Three screws hold the module - front and back plus left side at the bottom. A #2 Phillips screw driver will handle the job. After the screws are removed, as the module comes out, unplug any cables and antenna cables.

Reassemble in the reverse order

DTSS Tree Electronics



Align Status

Solid RED - Finish out of alignment
Solid GREEN - Speed out of alignment
Solid YELLOW - Finish and Speed out of alignment

RF Receive Status

Blink GREEN - Receive
Blink RED - Transmit

ID Code

e.g. 'C'

Optimizer Code

e.g. C17

Power

Blink RED/GREEN - Power ON

Battery

Insert USB Battery Pack



Fig. 6 - T-Link control center. The track sensor cable plugs into the T-Port connector.

T-Link bottom showing track position ID label.

'D' position is Right Lane Speed/Finish on optimizer code C30

Track sensor alignment can be monitored by observing the red/green LED.
This may be easier than using the console alignment diagnosis.




Fig 7 - Track layout. T-Link ID positions must be followed exactly.

KEYPAD FUNCTIONING

The console keypad utilizes dual function keys. All functions shown in white function when pressed; functions shown in yellow require the * [SHIFT] key to be pressed two seconds before the desired function key is pressed.

NAVIGATING TIMER MENUS

The XL Wireless Timer Console has a system diagnostic menu and two configuration menus:

The [*5 DIAG] Diagnostics menu includes Sensor Alignment, T-Link battery level and wireless RF signal integrity - functions used over the course of an event.

The [*4 SYSTEM] System menu includes Test sensors at race start, Printer setup, Speed Trap configuration and Timeslip Print Header - functions rarely changed during an event.

The [*8 CONFIG] Configuration menu includes Starting Tree selection, Race results to display when available and Race finish point - settings likely to change each race or class.

The selections made in these menus are saved - even when power has been turned off. The system selections can be printed by pressing *1 [REPORT] on the keypad.

Each menu will be covered in detail in upcoming sections of this manual.




Fig 8 - Console Keypad

2700 rev A.34.5 Configuration Parameters

--- Tree Settings			
Pre-Stage Lights		On	
Tree Input Power		110VAC	
Redlights Allowed		First	
Perfect RT=0.000		Off	
Tree Win Light Pattern		4	
--- Printer Settings			
Number of Line Feeds		10	
Autoprint copies		1	
--- Speed Trap Settings			
Trap Length		66 feet	
MPH (USA) or Km/H(Euro)		MPH	
--- Track Config Settings			
- Track Length (ID 'C' location)			
End of Race		1320ft	
Total Elapsed Time		ET	
Number of Lanes		Dual	
--- Track Sensors			
	Display	Test	
Dial-ins	Yes		
Reaction Time	Yes		
60 foot	No	Yes	
Mid-Track Speed	No	No	
Mid-Track ET	No	Yes	
Full Track Speed	No	No	
Full-Track ET	Yes	Yes	
--- Timeslip Header			
2700 Series XL Wireless			
Drag Timing System			
T-Link Wireless Technology			

Fig 9 - Printout of Configuration Parameters
Press [*1] [REPORT]

DEFINITIONS OF THE TREE LIGHTS




Fig 10 - The Tree displays sensor alignment by illuminating a bulb for each sensor position when in alignment mode or Intermediate alignment mode (left legends)
The Tree also displays a full variety of information during racing activity (right legend).

POWER-ON/SELF-TEST

Power is applied to each independent component of the system. Verify that antennas have been installed on all T-Link units including the Tree-Link and console before applying power.

First, it is best to turn on the T-Links at Half-track and Full-track Speed/Finish and verify alignment on the T-Links (see page 13); secondly, power on the Tree and the Tree goes into a self-test of the microprocessor circuitry. This is an internal test as well as a visual check of the Tree lights. The Tree sequences through a lamp test

and circuitry test by illuminating the left red lamp and stepping up through the green and yellows, Stage and Pre-stage (Pre-Stage Tree only) on the left side, then on the right side to Stage and Pre-stage (Pre-Stage Tree). This repeats rapidly and then all lamps are flashed once to conclude the self-test. When the tree has completed the self-test display, the system is fully functional and ready for final configuration and setup. If the lights do not follow this sequence or some lights were not illuminated, check for insufficient power, defective bulbs or bad cable connections. At the end of this power-up, the tree goes blank; Pre-Stage and Stage lights are active and may be




Fig 11 Diagnostic Menu, Press *5 [DIAG]

on until updated from the console. Third, connect the console to power; the console goes through a test and visual display of all segments in the display windows contained within the primary microprocessor. Normal communication is established with the Tree, the Tree lights will go out and the console will briefly show [uPdAtE] [trEE]. If communication is not established with the Tree; the display will briefly show [no] [trEE]. Press *0 [RESET] on the keypad to attempt to establish communications again if the tree is properly powered up also.

The test concludes when the upper console display shows the product model number [2700] and the lower display shows the code revision level [x.xx]. At the conclusion of the self-test, the Pre-Stage lights may be on until the system is reconfigured. Once the system has powered up, the Pre-Stage (if present and properly configured) and Stage sensors are active and indicate a vehicle present when blocked or misaligned.

If a printer is connected to the Console, press [*1] REPORT to print a summary of currently saved parameters. See Fig 7 for an example. Use this summary to determine what needs to be changed, if anything.

If scoreboards are connected, press **2 to send sample data to the scoreboards for display. It should show left lane with 12.345/135.79 ET/Spd and the right lane with 67.890/246.80 ET/Spd.

At the conclusion of the console power-up sequence, the system can be Configured (*8), Diagnosed (*5), operated (0) or put into background monitoring (#) mode.

BACKGROUND MONITORING

Background sensor monitoring gives the race director early warning about a possible problem and occurs when no other functions are being performed such as configure, print, enter dial-in or run a race. The background monitoring mode will display [SEnSor] [-tEst-] in the upper/lower windows if all sensors are aligned. If any sensors selected for test (*4) plus Finish are out of alignment, the display will show the offending positions in the following format - [l6SEsF] [r6SEsF] - where the upper/lower windows are left/right lanes respectively and the positions 60ft, Half-track speed, Half-track ET (T-Link IDs E&F), Full track speed and Full track ET (T-Link IDs C&D). Properly aligned sensors will show with a (-), misaligned sensors will show the position letter [l----F] [r----] and wireless units not connected (possibly no communications/no T-Link) will show three horizontal bars.

Background monitoring will automatically switch between [SEnSor] [-tEst-] and [l----F] [r----] as alignment conditions change. Background monitoring checks the sensors and updates the displays every five seconds. Use Alignment mode for continuous alignment setup and testing. Use background monitoring as a guide for starting races; a sensor out of alignment will not stop a race but may indicate a bad time or speed if ignored.

SINGLE or DUAL LANE OPERATION

The 2700 can operate in single or dual lane mode. This is configured in the 'Configuration' menu (*8888###). When in single lane mode (right lane), Pre-Stage/Stage lights for both lanes are controlled by the right lane, a single lane timeslip (Fig 12B) replaces the dual lane timeslip and only selected right lane sensors are monitored between runs.

Note: One lane in a dual lane setup can be operated without reconfiguring for single lane operation.

DIAGNOSTICS MENU (Fig 11)

SENSOR ALIGNMENT

All RaceAmerica timing systems have an alignment mode. This is very useful for verifying correct Emitter/Sensor alignment. Wireless systems have alignment checks at each T-Link which continuously displays alignment status with the left LED as well as live on the console and mirrored on the Tree. After the track layout has been determined and the Sensors and Emitters placed in the proper positions, use T-Link LED status to initially test alignment, then enter alignment mode section within the Diagnostics menu on the console by pressing the [*5#] **DIAG ALIGN ENTER** keys to verify correct alignment of START, 60ft, SPEED and FINISH (T-Link IDs C&D). Pressing the [*55#] **DIAG ALIGN ENTER** keys to verify correct alignment of 300ft (T-Link IDs G&H, 660ft SPEED and ET (T-Link IDs E&F) and 1000ft SPEED and ET (T-Link IDs J&L). Alignment conditions also display on the Tree as shown in the definitions of Tree Lights picture. The LED Display momentarily indicates the position of each sensor on the console display with letters representing each emitter/sensor pair [S6SESF]. The digits indicate Stage, 60 foot, Half-track Speed, Half-track ET, full-track Speed and Full-track Finish respectively. Left lane sensors are monitored in the top display and Right lane sensors in the lower display. The Status Display then changes each digit to a zero for each

sensor being monitored [000000]. If the Beam Emitter and Track Sensor are operating properly and aligned, the '0' digit will not change and the Tree lights will be OFF. If the Beam Emitter and Track Sensor are not properly aligned, the '0' digit for each emitter/sensor pair will count slowly if slightly out of alignment or continuously if they are not functioning properly, way out of alignment or not present (a triple bar [=] is displayed) and the corresponding Tree light will be on or flickering. Once the emitter/sensor pair are aligned properly, the digit will stop counting and the Tree light will go out. If the alignment is off a little or intermittent, the digit for that emitter/sensor pair will count when they float out of alignment. Note that the Pre-Stage position is always active on the Tree. It should also be noted that once the zero digit has started counting, it will never stop at zero again unless Alignment Mode is exited and re-entered. This can be helpful for leaving the system in alignment mode for an extended period of time to check on an intermittent condition.

To maximize the alignment of the emitter/sensor pairs, it is suggested to rotate the beam emitter slowly left and right until the alignment for that pair begins to count. This technique will determine the maximum lateral detection angle. Rotating the beam emitter up and down until the alignment starts counting determines the maximum vertical detection angle. Once these extremes are established, position the Beam Emitter in the center of the left/right detection angle and up/down detection angle. Repeat this same process with the other beam emitters and track sensors. This will maximize the alignment accuracy.

Remember, the beam emitters and track sensors operate on a 'Line-of-Sight' concept and may require shims if they are installed on a race track with a crown. Leaves, people, and other debris will also break the beams and could give false signals, so keep everyone and everything clear of the beam emitters and track sensors during racing activity. Lane width should be between four and fifty feet; eyeball a straight line between the two to get close.

Press the [#] **ENTER** key to exit Align Mode and return to Background Monitoring mode.




Fig 12 System Settings Menu, Press *4 [SYSTEM]

Ht-SPd and Ht-Et refer to T-Link IDs E & F,
SPEEd refers to IDs C & D; ET is always tested

If optional Dual-Beam (Stage with Guard beam) or Tri-Beam Start Line Track Electronics were purchased to add the True Guard Beam and Pre-stage beams to the Stage at the starting line, follow this alignment technique to properly align all beams.

If optional Guard beams are present, position the Dual/Tri-Beam Emitters and Sensors on the track and connect the start line cables as outlined in the timing system hardware manual. Power on the timing system and enter into alignment mode. Align the Pre-stage beams as usual and confirm Pre-stage beam alignment and operation. Next block the Stage beam on either the Dual/Tri-Beam Emitter or Sensor. With the Stage beam blocked, the Stage light on the tree will illuminate when the Guard beam is properly aligned. Rotating the Dual/Tri-Beam Sensor left or right on the track will cause the Guard beam to go out of alignment and the Stage light on the tree to go out. Position the Dual/Tri-Beam Sensor so the Pre-stage beam and the Guard beam are fully functional. This can be tested by blocking and

unblocking the Pre-stage (if present) and Guard beams. Unblock the Stage beam and the Stage light on the tree will go out. If the Stage beam does not go out, fine tune the positioning by slowly rotating the Tri-Beam left or right until the Stage light goes out. Recheck the Pre-stage and Guard beams for alignment.

To final check all three beams are properly aligned, block the Pre-stage beam and the Pre-stage light on the tree will illuminate. Block the Stage beam and the Stage light on the tree will illuminate. With the Stage beam blocked, block the Guard beam also and the Stage light on the tree should go out.

If all three beams are not aligned, check the parallel position of the Dual/Tri-Beam Emitter then repeat the Dual/Tri-Beam Sensor alignment process on the above rotating the Dual/Tri-Beams in smaller increments left or right.

NOTE: When beam emitters are powered on, a pink glow can be observed when looking into the emitter from close range; toggle the switch to observe the change (Use caution and look for only brief periods to avoid visual problems). Sensors get power for an internal red LED when connected to the cable. Checking for this light can confirm power is getting to each sensor.

BATTERY LEVEL

The T-Link battery charge level can be viewed by pressing ***555# [Shift Diag] [ConFiG] keys. [bAt Cd] [EFGHJL]** will display. The letters represent T-Link IDs. ‘C’ sensors (Full-track Left Lane Speed/Finish), ‘D’ sensors (Full-track Right lane Speed/Finish), ‘E’ sensors (660ft Left Lane Speed/ET), ‘F’ sensors (660ft Right Lane Speed/ET), ‘G’ sensor (330ft Left Lane), ‘H’ sensor (330ft Right Lane), ‘J’ sensors (1000ft Left Lane Speed/ET) and ‘L’ sensors (1000ft Right Lane Speed/ET). The letters will be replaced by the percentage of battery power remaining. 0 for 0%, 1 for 10%, 2 for 20%, etc and a dash for 100%. Any reading above 40% should be adequate for hours of operation.

Press **# [ENTER]** to return to Background Monitoring mode.

RF INTEGRITY

The T-Link RF signal integrity can be viewed by pressing ***5555# [Shift Diag] [ConFiG] keys. [rF tCd] [EFGHJL]** will display. The letters represent T-Link IDs. ‘t’ (Tree), ‘C’ sensors (Full-track Left Lane Speed/Finish), ‘D’ sensors (Full-track Right lane Speed/Finish), ‘E’ sensors (660ft Left Lane Speed/ET), ‘F’ sensors (660ft Right Lane Speed/ET), ‘G’ sensor (330ft Left Lane), ‘H’ sensor (330ft Right Lane), ‘J’ sensors (1000ft Left Lane Speed/ET) and ‘L’ sensors (1000ft Right lane Speed/ET). The dashes on the display will begin to count up as signals are received from the T-Link units on the track. 0 displayed represents 0%, 1 represents 10%, 2 represents 20% etc. until a dash appears representing 100%. This is an indication of the consistency of the RF

integrity. If this number jumps around, there is a high level of interference in the area. If the number remains high, the RF signal strength is very good. If the number remains low, the RF integrity is somewhat weak. The position of the T-Links and their antennas can be moved to optimize the RF Integrity level. Highly directional Yagi antennas may need to be considered to remedy a high interference location.

Press **# [ENTER]** to return to background monitoring.

SYSTEM MENU (Fig 12)

CONFIGURE SENSOR TEST

Select the sensors to be tested after a start request is sent to the tree and before the tree comes down; the Finish sensors are always checked. Press ***4 [Shift System] [ConFiG] [tESt]**. Press **# [ENTER]** to view the current selection for 60 ft sensors **[60 Ft] [on]**; press **[4]** to toggle to the opposite selection; press **[#] ENTER** to accept a choice and move to Half-track Speed **[Ht-SPd] [OFF]**; press **[4]** to toggle to the opposite selection; press **[#]** to accept a selection and move to Half-track ET **[Ht-Et] [on]**; press **[4]** to toggle to the opposite selection; press **[#]** to accept a selection and move to Full-track Speed **[SPEED] [OFF]**; press **[4]** to toggle to the opposite selection; press **[#]** to accept choice and return to background monitoring.

CONFIGURE TIMESLIP PRINTER

The number of timeslips to automatically print and the number or line feeds to eject a timeslip to tear it off.

Press ***44 [Shift System] [ConFiG] [Print]**. Press **# [ENTER]** to view the current selection for Printer Line feeds **[LF] [10]**; enter a new number using the keypad; press **[#] ENTER** to accept the number; next **[AutoPr] [1]** will show indicating the number of timeslips to autoprnt (blinking digit); press a number on the keypad (0-9) for the desired number of copies; press **[#] ENTER** to save and return to background monitoring.




Fig 13 - Configuration Menu, Press *8 [CONFIG]

CONFIGURE SPEED TRAP

Using wireless T-Link units, the cable supplied is long enough to set up any of the following speed trap lengths.

Press ***444 [Shift System] [ConFiG] [trAP]**. Press **# [ENTER]** to view the current selection for Speed Trap, cycle through **[trAP] [USA10]** for 10ft MPH trap, **[trAP] [USA66]** for 66ft MPH trap, **[trAP] [Euro3]** for 3 meter Km/PH trap, **[trAP] [Euro20]** for 20 meter Km/PH trap and **[trAP] [OFF]** by repeatedly pressing **[4]**, press **[#] [ENTER]** to accept the selection and return to background monitoring.

CONFIGURE PRINT HEADER

The XL Wireless allows a custom four line timeslip print header of up to 39 characters per line. Input is accomplished using character codes for each desired character position (see work sheets). Press ***4444 [Shift System] [ConFiG] [HEAdEr]**. Press **# [ENTER]** to view the setup dialog as follows **[L1 C01] [XX00]** indicating Line 1 Character 01; the XX is prompting for the character code for the desired character; refer to the worksheet for the correct code, press **[#]** to move to character 02 **[L1 C02] [YYXX00]** where YY is Character 01 and XX is prompting for character 02; continue for up to all 39 characters in the line. Press **[*]** to move to Line 2 **[L2 C01] [XX00]** and continue for all four lines. When done with all four lines, press **[*]** to return to background monitoring.

CONFIGURE MENU (Fig 13)

Use the Configure menu to select results to be displayed, how they are calculated, single or dual lane operation and a T-Link reprogram utility.

CONFIGURE TREE

Press ***88 [Shift ConFiG], [ConFiG] [tree]** displays. Press **# [ENTER]** to view the current selection for use of Pre-Stage lights **[PrE-St] [on]** which means Pre-Stage is ON and will function with the track electronics option; repeated presses of the **[8] CONFIG** key cycles the lower display through the other options. These include **[OFF]** which deactivates all Pre-Stage display, **[StAGE]** will turn on the Pre-Stage lights with the Stage lights, **[On]** will set Pre-stage to operate independently. Press the **[#] ENTER** key to accept the desired condition and move to power source **[trEE] [AC]**; press **[8]** to view **[trEE] [dtSS]**; press **[#]** to select the correct tree voltage and move to red lights to be displayed **[rEdS] [FirSt]** to display only the first lane to redlight. If both lanes redlight, press **[8]** to cycle to **[rEdS] [both]**. Press **[#]** to move to Reaction Time (RT) reporting **[rt 0.0] [Off]**. Select OFF to use the 0.400/0.500 reporting from the last yellow or select **[On]** to report RT from the Green light (positive or negative); press **[#]** to select the winning lane lights to display **[FiniSh] [LiGhtX]** where five choices for X (1-5) can be selected. Choice '1' displays winning lane, redlights and breakouts; choices '2-5' have animated winning lane displays only (go ahead, check 'em out); press **[#]** to go to background monitoring.

CONFIGURE DISPLAY

Use the Configure menu to select which results are displayed before, during and after a race. Results displayed on the console will also be sent to all scoreboards. Press ***888 [Shift ConFiG], [ConFiG] [diSP]**. Press **# [ENTER]** to view the current selection for Dial-ins **[diAL in] [on]**; press **[8]** to toggle to the **[diAL in] [Off]** which will not display dialins on the scoreboard. Press **# [ENTER]** to view the current selection for Reaction Time **[rT] [on]**; press **[8]** to toggle to not display RT. Press **# [ENTER]** to view the

current selection for 60 ft sensors **[60 Ft] [on]**; press **[8]** to toggle to not display 60 ft times. Press **[#] ENTER** to accept a choice and move to Half-track Speed **[Ht-SPd] [OFF]**; press **[8]** to toggle to not display Half-track Speed. Press **[#]** to accept a selection and move to Half-track ET **[Ht-Et] [on]**; press **[8]** to toggle to not display Half-track ET. Press **[#]** to accept a selection and move to Full-track Speed **[SPEED] [OFF]**; press **[8]** to toggle to display Full-track Speed. Press **# [ENTER]** to view the current selection for Elapsed Time **[Et] [on]**; press **[8]** to toggle to not display Full-track ET. Press **[#]** to accept choice and return to background monitoring.

CONFIGURE RACE

Use the Configure menu to select finish location (full-track or half-track) and how times are calculated (ET or ET+RT). Press ***8888 [Shift ConFiG], [ConFiG] [rACE]**. Press **# [ENTER]** to view the current selection for ending the race at 1320ft **[End] [1320]**; press **[8]** to toggle to 1000ft or 660ft for end of race; press **# [ENTER]** to view the current selection for total ET time reporting **[totAL] [ET]**; press **[8]** to toggle to **[Et rt]**; press **# [ENTER]** to view the current selection for one or two lane racing **[LAnES] [duAL]**; press **[8]** to toggle to **[SinGLE]**; press **# [ENTER]** to view **[Lby] [on]** to enable/disable 'Left before yellow' automatically ending a run in that lane. Make desired selection and return to background monitoring.

At this point the timer is ready to time the first run. It might be a good idea to recheck the sensor alignments after changing any configurations.

REPROGRAM T-LINK ID

Use the Configure menu to reprogram spare individual T-Links to an alternate ID. Place the reconfigure jumper into the T-Link T-Port to be reprogrammed, turn on the T-Link. Press ***8888 [Shift ConFiG], [rEProG] [idx]** will display. Press **# [ENTER]** to view the current ID **[idx] [to idy]**; press **[8]** to toggle to **[to idC], [to idd], [to idE], [to idF], [to idG], [to idH], [to idJ]**, or

[to idL]; press **# [ENTER]** to make the desired selection and return to background monitoring.

At this point the timer is ready to time the first run. It might be a good idea to recheck the sensor alignments after changing any configurations.

RUNNING A RACE

The system is now powered on, aligned and configured. Press the **[#] ENTER** key to clear any display condition and show background monitoring.

Next, race parameters for starting light sequence (Pro or Full), Dial-in times and Car numbers can be entered if time slips are to be printed or data capture software will be collecting race results. Select the desired starting sequence (Pro or Full) by pressing the **[3] TREE** key; the current Dial-in/Cross-talk and Tree will show as **[di Ct] [Full .5]**. 'di' indicates a non-zero Dial-in is currently entered (**[6]** key); 'Ct' means Cross-talk is active (by definition, Cross-talk only affects Full tree starts). Press **[3]** repeatedly to cycle through the other Tree options - **Pro .4, Full .4, Pro .5** - selecting the desired light by pressing **[#] ENTER**. After a selection, the display will show the current Cross-talk setting **[Ct] [OFF]**; press **[3]** to toggle to turn Cross-talk on; press **[#] ENTER** to close out Tree selections and display background monitoring.

The PRO format turns on all yellows then green at a 0.400 or 0.500 second interval to green. The FULL or SPORTSMAN format turns on each yellow, then green at 0.500 or 0.400 second interval between lights.

The Cross-talk option is similar to the NHRA Cross-talk function and is enabled for bracket racing under a FULL starting tree. When the slower vehicle's top yellow light illuminates on the tree, the top yellow in the other lane will also illuminate. The slower lane's yellows will illuminate in sequence as usual while the other lane's top yellow will remain illuminated until that lane's bracket advances to the next yellow. When Cross-talk is OFF, the tree starting sequence is not altered from normal starting sequences.

Each stored race configuration remains the

starting settings until changed (Car #, Dial-in, starting tree) or power is cycled off.

If running brackets, press the **[6] DIALIN** key to view the current Dial-in times; press the **[6]** key again to zero out the existing times and enter new numbers (top display is for left lane and bottom display is for right lane times); input the racers Dial-in times. Press the **[#] ENTER** key to accept the new times (all zeros will be heads-up format). Bracket racing is a form of handicapping where the expected Elapsed Time is entered for each racer, the starts are adjusted so both racers with perfect reaction times and both run their Dial-in, they will finish at the same time. If either racer runs faster than their Dial-in time, they 'Breakout' and this will be displayed after the

race by illuminating the middle yellow light on the Tree if Finish Light sequence [1] was selected; it will also print on the timeslip.

Press the **[9] CAR #** key to view the current Car numbers; press the **[9]** key again to zero out the existing times and enter new numbers (top display is for left lane and bottom display is for right lane times) input the racers Car numbers. Press the **[#] ENTER** key to accept the new numbers (all zeros is acceptable). This information will appear on timeslips and in data captured in PCs after the race.

Stage the race vehicles by moving them into the Pre-Stage (if present) and Stage beams (Pre-Stage and Stage lights on the Tree come on).

To start the race, press the **[0] RUN** key. The

2700 Series XL Wireless Drag Timing System			
T-Link Wireless Technology			
1234	Car Number		9876
Left	by 1.47	WIN	Right
0.955	Reaction Time		0.697
NO	Redlight		NO
0.000	Dial-in/Index		0.000
NO	Breakout		NO
2.813	60 Ft Time		2.931
5.813	330 Ft Time		5.906
115.26	660 Ft Speed		128.27
9.301	660 Ft Time		8.303
130.32	1000 Ft Speed		141.64
12.183	1000 Ft Time		11.108
143.45	Vehicle Speed		160.63
14.351	Elapsed Time		13.303
Timing by RaceAmerica's T-Link Wireless www.raceamerica.com			

Fig 14A - Dual lane timeslip example

2700 Series XL Wireless Drag Timing System	
T-Link Wireless Technology	
Car Number	4321
Reaction Time	0.527
Redlight	NO
Dial-in/Index	0.000
Breakout	NO
60 Ft Time	2.742
330 Ft Time	3.514
660 Ft Speed	70.24
660 Ft Time	5.402
1000 Ft Speed	82.36
1000 Ft Time	7.635
Vehicle Speed	94.36
Elapsed Time	8.899
Timing by RaceAmerica's T-Link Wireless www.raceamerica.com	

Fig 14B - Single lane timeslip example




Fig 15 - Model 2700 Keypad

Tree will begin the starting light sequence. If a driver interrupts the starting beam prior to the green lamp illuminating in that lane, the starting sequence will stop for that lane, freezing the tree and illuminating the red/yellow lamps indicating a redlight start in that lane. Once a driver crosses the starting line, they must cross the finish line to complete their run. As the race progresses, the displays (and connected scoreboards) will display selected intermediate data ([*88] [CONFIG] [DISP]) as it becomes available. The Tree will continue to illuminate the red or green lamps until both lanes have crossed the finish line (or only one lane crosses the finish line in the case of a BYE run). When both vehicles cross the finish line, the Display will indicate the Elapsed Times (ET or ET+RT if selected).

After both lanes have completed their runs, the Tree will display the redlight conditions of each lane if Finish Light sequence [1] was selected. The selected Finish Light sequence will be illuminated for the winning lane after applying NHRA rules for reaction time, breakouts, redlights, and first to cross the finish line. If a printer option is present, the selected number of timeslips will print. [Print] [SLiP] will display in window after a race when

printing is occurring. Additional prints can be made by pressing the [*7] PRINT key. If a Scoreboard option is present, the Scoreboard will display the selected information (ET/SPEED).

The Console Display will show the **Left ET** in the upper display and the **Right ET** in the lower display; a box [o] to the left of one ET indicates the winning lane. After each race, the race data can be displayed: Press [1] to view Reaction Times, press [2] to view 60 ft times; press [7] to view Speed, if Half-track ET is connected, press [5], press [4] to view Half-track Speed.

Race results are available for recall and reprint until the [0] key is pressed for a new race.

Dial-in racing is started by pressing the [6] DIALIN key on the Keypad to display current Dial-ins, then press [6] again to enter the Dial-in for the Left and Right lanes; the next start will apply the appropriate differential to the starting sequence of the race. At the end of a Dial-in race, the Tree will additionally indicate a bracket breakout if one occurs on either lane by illuminating the center yellow light if Finish Light sequence [1] was selected. Dial-in selections can be checked by pressing the [6] key.

NOTE: As a general rule, if the Tree has a green or red lamp illuminated, one of the lanes has not completed its run and crossed the finish line. The [#] ENTER key must be pressed by the operator to end the race and capture the data up to the point of the problem.

TIME & COUNT FUNCTIONS

The console and network scoreboards have a provision to set a twelve hour clock and display time on connected scoreboards. Additionally, a 60 minute countdown timer can be used to time breaks in the race action.

To set the time of day, press [*6] TIME and enter a valid time of day; press [#] ENTER to send the time to the scoreboards. Press [#] ENTER

again to clear the display and scoreboards. Press [*6] to view time on the console. To start the countdown clock, press [*9] **COUNT** and enter a beginning countdown point (e.g. 2000 for 20 minutes), press [#] **ENTER** to send the countdown status to the display and scoreboards; press [#] **ENTER** again to clear the countdown. Press [*9] to view time remaining on the console.

KEYPAD FUNCTIONS

The Model 2700 Drag System utilizes a second function keypad; functions printed in white operate when pressed; functions printed in yellow require the ‘SHIFT’ button to be pressed two seconds before the desired second function yellow key is pressed.

The following defines the keypad key functionality:

KEY 0

The [0] **RUN** key is used to start a race.

KEY 1

To display the RT results from the last run, press the [1] **RT** key to view Reaction Times for both lanes; press [#] to clear.

KEY 2

To display the 60 ft ET results from the last run, press the [2] **60FT** key to view 60 ft ETs for both lanes; press [#] to clear.

KEY 3

Press the [3] **TREE** key to view the currently selected starting tree; press [#] **ENTER** to accept. Repeated presses of the [3] **TREE** key cycles through the available starting light sequences:

PRO 400	(standard)
FULL 400	(optional)
PRO 500	(optional)
FULL 500	(standard)

A PRO Tree illuminates all yellows, then Green at the selected interval; a FULL Tree (also known as SPORTSMAN Tree) illuminates each yellow, then green at the selected intervals.

KEY 4

To display the HALF TRACK SPEED results from the last run, press the [4] **HT SPD** key to display Half Track Speed results for both lanes; press [#] **ENTER** to clear.

KEY 5

To display the HALF TRACK ET results from the last run, press the [5] **HT ET** key to display Half Track Speed results for both lanes; press [#] **ENTER** to clear.

KEY 6

The [6] **DIALIN** key is used to recall and enter the bracket or index for each lane. Press the [6] key to view the current Dial-Ins; press the [6] key again to change the times. Press the [#] **ENTER** key to accept the changes.

KEY 7

To display the FULL TRACK SPEED results from the last run, press the [7] **SPD** key to display speed for both lanes; press [#] to clear.

KEY 8

To display the ET results from the last run, press the [8] **ET** key to view Elapsed Times for both lanes; press [#] to clear.

KEY 9

The [9] **CAR#** key is used to enter the Car number for each lane. Press the [9] key to view the current Car numbers; press the [9] key again to change the times. Press the [#] **ENTER** key to accept the changes.

KEY*

The [*] key is used as a ‘SHIFT’ key to enter the second key function modes (Yellow type).

KEY #

The [#] **ENTER** key is used to accept input values, end races without a finish or clear the Tree.

KEY *0

To manually reset the console, press [*0] **RESET** and be ready to continue.

KEY *1

To print the system configuration report, press [*1] **REPORT**.

KEY *2

To put the system in a 'hold' situation and indicate such to the racers, press [*2] **EMERG** to indicate some form of emergency, press [#] to return to background monitoring.

KEY *3

To set brightness levels on scoreboards used with the 2700 system. When data is displaying on the scoreboard, press [*3] to enter Brightness mode, then press keys 1 thru 8 to set the desired brightness level (1 is brightest, 8 dimmest). Press [#] when done. Scoreboards must be firmware level H.x or later. The scoreboards will retain this setting as long as they are powered ON.

KEY *4

Press the [*4] **SYSTEM** key on the Keypad to enter the system configuration menu to set test, print, speed trap and custom header parameters. See Fig 10 for the full menu.

KEY *5

To review system diagnostics (Sensor Alignment, Battery Levels and RF Signal Integrity), press [*5] to enter the **DIAGNOSTIC** mode. Repeated presses of the [5] key will cycle between the different sections; press [#] **ENTER** to monitor the displayed status; press [#] **ENTER** again to return to system operation. See the section on **ALIGNMENT MODE** earlier in this manual. See Fig 9 for the full menu.

KEY *6

Press the [*6] **TIME** key on the Keypad to set

the time of day for display on scoreboards used with the 2700. The time is maintained until new data is received or the scoreboard is powered on. Scoreboards must be firmware level H.x or later

KEY *7

To manually print the timeslip to the printer, press the [*7] **PRINT** key. This can be done at any time to verify cabling and printer settings; race results in a test condition may all be zeros.

Non-RaceAmerica printers connected to the XL Wireless system must be configured for RS232 serial communications, 9600 baud, No Parity, 1 Stop Bit, No Handshake; these parameters can be set on the printer (a custom cable may be required).

KEY *8

Press the [*8] **CONFIG** key on the Keypad to enter the system configuration section menu to set Tree, Data Display and race finish point. See Fig 11 for the full menu.

KEY *9

Press the [*9] **COUNT** key on the Keypad to set a countdown timer up to 60 minutes on scoreboards used with the 2700. The countdown continues until it reaches zero, new data is received and power is ON. Scoreboards must be firmware level H.x or later.

KEY *#

LED Tree brightness (see *3 for operation).

KEY **2

Press [**2] to send test data to scoreboards.

STATUS DISPLAY MESSAGES

During normal operation, messages will appear in the Console Display. These messages indicate status, mode of operation, or events occurring on the race track. Many of these messages are covered elsewhere in this manual and are alphabetically summarized in the following section as a reference:

ALiGn

This message indicates the system is entering the alignment mode for checking the alignment of the emitter/sensor pairs on the track.

AutoPr

Displays in the upper display during configuration for the number of timeslips to auto print after each race.

DiALin

Displays in upper display when selecting the starting Tree format if a Dial-in other than zero is entered.

End

This messages indicates all starting vehicles for that pair of lanes have crossed the finish line and the run is over.

Full

Full (Sportsman) starting format Tree is selected.

LF

During configuration of the printer, the user is prompted to enter the desired number of line feeds to be added to each timeslip to properly eject the paper for tear-off from the printer.

OFF

Displays for selection to disable various options.

on

Displays for selection to enable various options.

PC EnAbLE

Displays when PC is in command. Marks PC only functions.

PrE-St

Displays in the upper display during configuration or Pre-Stage functionality.

I---F

Background monitoring is indicating the left

finish sensor id out of alignment.

SEnSor tESt

Displays when background sensor monitoring is active and all sensors are properly aligned.

S6SESF

When entering Alignment Mode, this message will appear in sequence to indicate the alignment of the Track Sensors and Beam Emitters will be continuously monitored and the results displayed; left lane in upper display, right lane in lower display (Start, 60ft, Half-Track Speed, Half-Track ET, Full-Track Speed, Full-Track Speed).

Print SLiP

Indicates timeslip data is being sent to the printer ports..

Pro

PRO starting format Tree is selected.

SPEEd

Displays in configuration setup to enable or disable the Speed option. If sensors are not connected to the system, Speed must be OFF.

StAGE

Appears in the Pre-Stage configuration; selection of Stage will turn on the Pre-Stage lights when the Stage lights come on as a vehicle stages.

60 Ft

Displays in configuration setup to enable or disable the 60 Ft option. If sensors are not connected to the system, 60 Ft must be OFF.

TROUBLE SHOOTING

Some operational conditions which may cause operational problems or be symptomatic of problems which should be addressed are listed here with solutions.

Alignment problems - Use new emitter batteries; interchange positions of similiar units to

isolate specific emitter, sensor or cable problems; disable positions to continue event.

Tree Light turns ON/OFF - Using Alignment Mode, switch sensors to isolate the problem to the tree, cables or sensors.

Intermittent flickering of tree lights - check power supply for momentary over voltage condition.

System resets at power-up or when the Tree comes down - Check power supply for low voltage condition; may manifest itself as a generator surging or bogging down; check for adequate wire gauge on long power runs and extension cords.

Scoreboards do not display correct results. After determining the communications are correctly cabled or wired, press **2 from the keypad to display simulated race results. The scoreboards should show 12.345/135.79 for the left lane ET/Spd and 67.890/246.80 for the right lane ET/Spd.

CONNECTING PERIPHERAL DEVICES

The XL Wireless console can be connected to a variety of peripheral devices including PCs, Printers, Scoreboards and a Starter's Button. The printer is connected via cable or wireless RF data links.

The **Starter's Button** (06-27SB) connects at the starting line on the back of the tree. The Starter's Button functions exactly as the **[0] RUN** console key and in parallel with it.

Other peripherals are connected via Wireless RF Links which work best with line of site operation and operate to distances in excess of a quarter mile.

RaceAmerica Scoreboards (models 6828, 6628, 6428, 6810, 6610 and 6410) can be connected with internal or external wireless units. Scoreboard data is sent immediately and automatically at the conclusion of a race as the data is displayed on the console. Scoreboards contain internal 'smarts' to sort the data string and display

the race results (selected by DIP switch settings on each display unit). Choices include Left/Right Lane data, ET, Speed, RT, winner indication (flash winning lane) or alternating between Speed and ET (6828,6628 and 6428 models only). Additionally, eight brightness levels, time of day display and a countdown timer are available for special situations and managing your event.

A printer is a desirable peripheral to print timeslips for the participants. Printers receive a special output format transmitted serially at 9600 baud.

RACE MANAGEMENT SOFTWARE

RaceAmerica XL Score PRO Race Management Software can be used to control the Model 2700 XL Wireless timing system to manage the racing action. XL Score PRO is PC based software which includes Classes, Driver Registration, Practice, Qualifications, Eliminations Ladder creation (up to 64 cars per class) and status output in HTML format for viewing in networked web browsers. See the XL Score PRO manual (part no. 3128B) for additional details. Some 2700 functions are not available in PC mode.

WIRELESS FIRMWARE UPDATE

The 2700 console internal firmware (A.31 and later) can be updated in the field using a PC Utility program and the wireless network. A wireless link unit on the same optimizer code as the console is required with the PC. If using XL score Pro software, the PC wireless modem will work with the utility software. Follow on-screen instructions with utility to complete the update. Call RaceAmerica for details.

MAINTENANCE

The 2700 Series Console, Beam Emitters, and Track Sensors do not require any maintenance beyond simple cleaning. Keep your system components dry between uses.

To insure uninterrupted operation on raceday, it is suggested to keep track of battery usage hours

so as to have fully charged batteries. T-Link units should be kept at more than 40% charged. Plan to replace the alkaline AA cells in the Beam Emitters after about 60 hours use. If you are using rechargeable AA cells, recharge them each day. Low battery voltage (Emitters below 4.5VDC) will cause intermittent operation of the system resulting in intermittent cars detected at the starting line or the finish line as the battery power weakens.

To maintain the highest level of timing accuracy and minimize false trips, annual preventative maintenance and calibration should be performed on all system track sensors and beam emitter units.

SPARE PARTS

To minimize race program interruptions, RaceAmerica recommends the purchase of spare parts. A spare emitter/sensor pair and end of track cable sections should be available in the event of an unfortunate accident during a program. Contact RaceAmerica for availability and pricing of spares items.

SUPPORT AGREEMENTS

Support agreements are available from RaceAmerica providing Telephone Assistance on technical issues and operational questions, repair and/or replacement of hardware failures, Software and Firmware updates and bug reporting, and Annual Preventative Maintenance on all system track sensors and beam emitter units. Contact RaceAmerica for more information and pricing of Support Agreements.

TIMESLIP HEADER

The 2700 Series Console allows custom timeslip header input for four lines of up to 39 characters each to print at the top of each timeslip. Input for the Timeslip Header is found in the **[ConFig] [HEAdEr]** menu. Once the configuration is input, it is saved until changed or deleted. Input is from the keypad via a two-digit code for each character. The console display prompts for each line, character and character code (existing or new) being input.

The following table lists the codes for each character (note: upper and lower case letters have different codes). Use the worksheet on the next page to lay out the desired print text and cross-reference the codes for sequential input. Only desired text including spaces need to be input for each line; any line or lines can be left blank also.

Character	Code	Character	Code	Character	Code
Space	00	A	33	a	65
!	01	B	34	b	66
@	02	C	35	c	67
#	03	D	36	d	68
\$	04	E	37	e	69
%	05	F	38	f	70
&	06	G	39	g	71
'	07	H	40	h	72
(08	I	41	i	73
)	09	J	42	j	74
*	10	K	43	k	75
+	11	L	44	l	76
'	12	M	45	m	77
-	13	N	46	n	78
.	14	O	47	o	79
/	15	P	48	p	80
0	16	Q	49	q	81
1	17	R	50	r	82
2	18	S	51	s	83
3	19	T	52	t	84
4	20	U	53	u	85
5	21	V	54	v	86
6	22	W	55	w	87
7	23	X	56	x	88
8	24	Y	57	y	89
9	25	Z	58	z	90
:	26	[59	{	91
;	27	v	60		92
<	28		61	}	93
=	29]	62	~	94
>	30	'	63		
?	31	'	64		
@	32				

Fig 16 - Timeslip Header Character Codes


TIMESLIP LAYOUT WORKSHEET

Character Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39						
Printed Character																																													
Character Code																																													
Printed Character																																													
Character Code																																													
Printed Character																																													
Character Code																																													
Printed Character																																													
Character Code																																													

Line 1
Line 2
Line 3
Line 4

Fig 17 - Timeslip Header Character Code Worksheet

7540 - Foam Stand Assembly Instructions



Base Foam

Top Foam

Assembly Components

USB Battery Emitter (5040, 5050 & 5058)

1. Install battery pack.
2. Separate the Base of the Foam Stand from the Top.
3. Place the 5040/5050/5058 Emitter into the Base foam with the battery side down.
4. Slide the Top on the Base paying attention to the four corner pins and their alignment with the corresponding Base holes. Place on the track.



Sensor/Emitter placement in Foam Base

Track Sensor (5140 & 5158)

1. Separate the Base of the Foam Stand from the Top.
2. Connect the cable to the sensor
3. Place the 5140/5158 Sensor into the base (open end down)
4. Slide the Top on the Base paying attention to the four corner pins and their alignment with the corresponding Base holes. Place on the track.



Sensor back
Note cable routing

USB Battery Emitter (5042)

1. Same as above except place the battery pack.
For additional stability

1. Place weight in the Base well as required.

Outside Dimensions:

6.5" W x 7.25" L x 7.5" H



Complete Assembly