

Mounting Instructions for 4590B Flat Panel Antennas

To assemble the pole mounting bracket on the flat panel antenna, position the antenna with the label in center as shown in Figure 1, with the arrow pointing up.



Figure 1

Place the large mounting bracket on the studs to the right of the N-Connector and attach with two lock nuts, as shown in Figure 2. This bracket may be reversed, depending on your mounting requirements.



Figure 2

Attach the L bracket, with the swivel end mated to the large bracket, as shown in Figure 3. Attached with bolt and remaining lock-nut.



Figure 3

Attach pole clamp and bracket, as shown in Figure 4, to your mounting pole. Tighten all bolts.



Figure 4