


## 7540C - Foam Stand Assembly Instructions



Assembly Components

### **‘AA’ Battery Emitter (5040B, 5050B & 5058B)**

1. Install batteries and turn on the Emitter.
2. Separate the Base of the Foam Stand from the Top.
3. Place the 5040/5050/5058 Emitter into the Base foam with the battery side down.
4. Slide the Top on the Base. Place on the track.



Sensor/Emitter  
placement in Foam Base

### **Track Sensor (5140D & 5158D)**

1. Separate the Base of the Foam Stand from the Top.
2. Connect the cable to the sensor
3. Place the 5140/5158 Sensor into the base (open end down)
4. Press the Top on the Base. Place on the track.



Sensor back  
Note cable routing

### **‘C’ Battery Emitter (5042B)**

1. Same as above except place the ‘C’ Battery pack in the Base standing on its edge.

For additional stability

1. Place weight in the Base well as required.

Outside Dimensions:

6.5” W x 7.25” L x 7.5” H



Complete Assembly