



INNOVATION. TECHNOLOGY. RELIABILITY.

## ***T-Link Wireless***

### ***Model 06-58AX ID Reconfigure Kit***

Rev B1



**RaceAmerica Corporation**  
**62 Bonaventura Drive**  
**San Jose, CA 95134**  
**(408) 988-6188**  
**[www.raceamerica.com](http://www.raceamerica.com)**  
**[info@raceamerica.com](mailto:info@raceamerica.com)**

Copyright 2025 RaceAmerica Corporation

## PACKAGE CONTENTS

This package contains five T-Link Reconfigure Jumpers labeled for their specific position (A, B, C, D or Z) as used on a race course.

## RECONFIGURING T-LINKS

T-Link identifier codes are preset at the factory for use in specific locations on the race course. Using an external Reconfig Jumper (06-58AX), a T-Link's ID code can be changed enabling a single backup unit to replace any unit with the same optimizer code.

To temporarily change the ID code of a T-Link unit, power the unit off. Select the Reconfig Jumper with the desired ID code (A, B, C, D or Z) and install it into the T-Port connector of the T-Link unit to be reconfigured. Power on the T-Link unit. The LED will flash three short

times to confirm the T-Link unit has been reconfigured to the new ID code. Unplug the Reconfig Jumper and connect any cables to the T-Link unit for normal use. Do not power off the T-Link unit after a new ID code has been assigned. The change of ID is temporary. When the T-Link unit is powered off, the ID code will revert back to the preset ID shown on the bottom of the T-Link unit.

These jumpers will work with any optimizer code, however, all T-Links in a network must have the same Optimizer Code. The Optimizer code can be found on the ID label on the bottom of the T-Link next to the ID code.




Figure 1 - T-Link power and external connections

## REVISION HISTORY

- A - 10/07 - Initial release
- B - 01/14 - T-Link2 update/cover pic